



Adventure and Sports Carrier dims.

Centre Bike Channel is 550 from Centre Hitch Pin hole

Contact us if you have:

Spare Tyre, Ladder, Jerry Cans behind canopy

X = Extra length required



X

Hitch Pin Hole

If your bike is 900 across the bars $\div 2 = 450$

X + standard 550 = 100mm clearance from inside bar to canopy

If X is 300mm, you need a 300 longer main bar to maintain 100 clearance from canopy. That's if your handlebars are 900 wide.
PHONE to discuss if needed. Thanks.